

• • • —————•

Review of Plutonium Attribute Measurement Technologies: Gamma-Ray and Symmetry Measurements

**Thomas Gosnell
Lawrence Livermore National Laboratory**



What This Talk Will Cover

Attributes	Methods	Sensors
Plutonium age Presence of Pu	Pu-300	High-purity Ge (50%)
Presence of Pu Presence of WG Pu	Pu-600	
Absence of PuO ₂	Pu-900	High-purity Ge (100%)
Symmetry	nSymmetry	Neutron singles detectors





Gamma-Ray Methods


- **Elements common to each of the gamma-ray measurements**
 - **Collect only the data required**
 - **Measurement geometry**
 - **Source and geometry independence**
- **Elements specific to each of the gamma-ray measurements**
 - **Pu-300**
 - **Pu-600**
 - **Pu-900**




Collect Only the Data Required



Pu-300



Pu-600



Pu-900




Gamma-Ray Measurement Geometry



Both the Pu-300/600 detector and the Pu-900 detector view the source through the neutron multiplicity counter (NMC).



Source and Geometry Independence




- > To achieve this independence we:
- Fix the source/detector distance
 - Fix the counting interval

We do this by:

- Employing a massive shield
- An autonomous tungsten iris
 - Optimizes count rate
 - Shrouds the counting geometry

<



Why Use Two Gamma-Ray Detectors?

- To save time—to make the measurements in narrow energy bands, three separate measurements must be made.

Detector 1

The Pu-300 and Pu-600 measurements are made serially


Pu-300 (age attribute)
Pu-600 (weapon-grade attribute)

Detector 2


Simultaneously, the Pu-900 measurement is being made
Pu-900 (absence of
PuO₂ attribute)



Pu-300—Plutonium Age / Presence of Pu



- Pu age since separation determined by the ratio of ^{241}Am to ^{241}Pu .
- The ratio of the 332.4 and 335.4 keV lines is a function of time because they are populated at different rates in the two decay branches.





- Presence of Pu indicated by the 345.0 keV ^{239}Pu line.




Pu-600—Weapons-Grade Pu / Presence of Pu

- Weapons-grade plutonium:
 - For weapons-grade plutonium:
 $^{239}\text{Pu} + ^{240}\text{Pu} \approx \text{Total Pu}$.
 - Therefore, if the ratio
 $^{240}\text{Pu} / ^{239}\text{Pu}$ is low, the material
is weapons-grade.
 - This value is also used in
conjunction with the neutron
multiplicity data to determine
the plutonium mass.
- Presence of plutonium:
 - 646 and 659 keV peaks.
 - Determination of presence
requires *both* the 345 keV peak
from Pu-300 and the 646 and
659 keV peaks from Pu-600.



Weapons-Grade Pu Presence in Storage Containers— Pu-600 Method Measures $^{240}\text{Pu}/^{239}\text{Pu}$ Ratio

- Uses commercial equipment
- A variant of MGA plutonium isotopics code
- Successfully tested against a variety of Pu objects in various types of containers




Successfully tested against a variety of Pu objects in various types of containers



Pu-900—Verify Absence of PuO₂: A Work in Progress

- We use the 870.8 keV gamma ray from the first excited state of ¹⁷O as an indicator of the presence of PuO₂.
- The source of this gamma ray is somewhat ambiguous.
 - It is known to arise from coulomb excitation (α, α'), likely due to alpha decay of ²³⁹Pu.
 - It may also be due to an (α, p) reaction from nitrogen impurities.
 - Experiments to resolve this ambiguity are underway.
- Our experience shows that this peak is always present in PuO₂ and not present in Pu metal.




- A shoulder peak is sometimes observed and is easily resolved.
- The origin of this peak is also under investigation.





Neutron Method for Measuring Symmetry

- Under some circumstances, it may be important to know if the object in a storage container is cylindrically symmetrical.
- We test for cylindrical symmetry as indicated by an isotropic neutron radiation field:
 - suggested by the Russian Federation at Moscow talks in 1996
 - US/Russian Federation experiments tested the method at LLNL in November 1996.



Cylindrical Symmetry as Indicated by an Isotropic Neutron Radiation Field



- Ideally, if the item is cylindrically symmetrical, the neutron counts in all detectors will be equal.
- We test for a significant variation from equality:

$$s = \max \left(\frac{|y_i - \bar{y}|}{\bar{y}} \right), \quad \sigma_s = \frac{\sqrt{y_i}}{\bar{y}}$$

- To fail the symmetry test, both s and s/σ_s must be large (>0.15 and >3).

