



An Example of a Measure for Increased Confidence in Authentication

**Richard Morgado
M. William Johnson
Los Alamos National Laboratory**



Authenticating an Instrument: Several Aspects

- • •
- Demonstrate that hardware and software contain the agreed elements and nothing else.
- Demonstrate that the system functions as it should.
- Demonstrate that the system remains unchanged since the last authentication.
- Other considerations.

The emphasis in this part of the demonstration is on the second aspect:

—*demonstrate that the system functions as it should.*



Authentication Sources

- The authentication sources were chosen to provide confidence that the system is functioning according to specifications.
- In an eventual measurement regime, the sources themselves may require authentication.
- For this demonstration, detailed analysis of the sources is not feasible owing to constraints of time, security, and the lack of an enabling agreement.
- However, it is possible to introduce the *concept* of authentication of the sources at this time.



• • • Authentication Sources

- During an earlier exchange, Russian representatives suggested the value of examining the authentication sources with an instrument of Russian origin.
- This cannot be done in the present demonstration for administrative reasons (without prejudice to the possibility of performing similar measurements in another venue).
- Instead, a U.S.–supplied and –operated instrument is available, and the data generated by it can be displayed. This is called the “independent measurement instrument” in this presentation.



Independent Measurement Instrument

- **HPGe detector**
- **DART™ analyzer (functionally similar to the “Green Star” analyzer)**
- **Laptop computer running control and display software**

All system components are commercially available.



• • • **Measurement Plan**

- **While the second AMS/IB authentication measurement is in progress, the source used in the first authentication measurement is available for examination with the independent measurement instrument.**
- **To save time and simplify the demonstration, calibration of the independent measurement instrument will already have been performed.**
- **U.S. personnel will control the instrument, but Russian Federation personnel are invited to direct acquisition, regions of interest, etc.**
- **The instrument will be removed before presentation of the weapon component.**



Features That May Be Visible

- **Pu presence: Region near 400 keV**
- **“Isotopic” region: 600–700 keV**
 - **Software for detailed isotopic analysis is not available.**
 - **^{240}Pu line at 642.5 keV can be detected visually after a few minutes’ counting.**
 - **To the experienced spectroscopist, spectrum “shape” is distinctive.**
- **Pu age: region near 330 keV**
 - **Analysis software not loaded.**
 - **Data difficult to interpret visually.**
- **Oxide indicator (871 keV) will be difficult to see.**

